

SUSPENSION AND AXLE

TROUBLESHOOTING

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order. If necessary, replace these parts.

Trouble	Parts Name	See Page													
			Tires	Cold tire inflation pressure	Wheel alignment	Springs	Stabilizer bar	Shock absorber	Ball joint	Hub bearings	Steering linkage	Steering gear	Suspension parts	Overloaded	Wheel balance
Wander/pulls		-	1		2					4	3	5	6		
Bottoming						2		3						1	
Sways/pitches			1				2	3							
Front wheel shimmy			1		4			3	5	6	7	8			2
Abnormal tire wear				1	2			4					3		