## PREPARATION SST(SPECIAL SERVICE TOOLS)

	07110–58011 Air Conditioner Service Tool Set	
O LARS	(07117–58010) Refrigerant Dram Service Valve	
	(07117–78011) Refrigerant Charging Gauge	
8	(07117–88013) Refrigerant Charging Hose	Green color
ar Co	(07117–88022) Refrigerant Charging Hose	Blue color
an Au	(07117–88040) Refrigerant Charging Hose	Orange color
DEREM DEREM	(—) Stop Valve	
•/////	07110–61050 Wrench Set	
	07110–77011 Magnetic Clutch Tool Set	
and the	07112–15010 Seal Plate Remover	
OD	07112–25010 Shaft Seal Remover	
	07112–45021 Key Remover	
<b>S</b>	07112–71010 Magnetic Clutch Remover	

	07112–76040 Magnetic Clutch Stopper			
	07114–15010 Seal Plate Presser			
5				
0	07114–45010 Key Replacer			
	07114–84020 Snap Ring Pliers			
	07116–38330 Gas Leak Detector Assembly			
	07117–48050 Vacuum Pump Assy	Rated voltage AC220V		
<b>A</b>	07117–48060 Vacuum Pump Assy	Rated voltage AC240V		

## **RECOMMENDED TOOLS**

AC008--05

AC009-02

63	09082–00015 TOYOTA Electrical Tester	
to to the		

## EQUIPMENT

Part NameNoteVoltmeterMeasures voltageAmmeterMeasures currentOhmmeterMeasures resistance

## LUBRICANT

Item	Capacity	Classification
Compressor oil When replacing receiver When replacing condenser When replacing evaporator	20 cm³ (0.7 fl. oz.) 40−50 cm³ (1.4−1.7 fl. oz.)	ND OIL6
4	40-50 cm <sup>3</sup> (1.4-1.7 fl. oz.)	

ACODF-01