EMISSION CONTROL SYSTEMS

SYSTEM PURPOSE

1906T-0

System	Abbreviation	Purpose
Positive crankcase ventilation Fuel evaporative emission control Exhaust gas recirculation Three—way catalyst Electronic fuel injection*	PCV EVAP EGR TWC MPI	Reduces blow–by gas (HC) Reduces evaporative HC Reduces NOx Reduces HC, CO and NOx Regulates all engine conditions for reduction of exhaust emissions.

^{*} For inspection and repair of the MPI system, refer to MPI Section.

V01052

PREPARATION SST (SPECIAL SERVICE TOOLS)

8906U-01

20	09843-18020 Diagnosis Check Wire	

RECOMMENDED TOOLS

E006V --



09082-00015 TOYOTA Electrical Tester

EG05W -- 01

EQUIPMENT

Heater	TVS
Thermometer	TVS
Tachometer	
Torque wrench	
Vacuum gauge	

SSM (SPECIAL SERVICE MATERIALS)

E006X-0

08833–00070 Adhesive 1324, THREE BOND 1324 or equivalent	TVS